
































Assembly Guide

US-PF005-X




READ AND SAVE THIS INSTRUCTIONS FOR FUTURE USE


ASSEMBLY & INSTRUCTION MANUAL

<p>Ax1</p> 	<p>Gx1</p> 	<p>Mx1</p> 	<p>④x10+1</p>  <p>M3. 5*40mm</p>	<p>⑩x4</p> 
<p>Bx1</p> 	<p>Hx1</p> 	<p>Nx1</p> 	<p>⑤x3</p>  <p>M6*30mm</p>	<p>⑪x2</p> 
<p>Cx1</p> 	<p>Ix1</p> 	<p>Ox1</p> 	<p>⑥x14+1</p>  <p>M6*45mm</p>	<p>⑫x2</p> 
<p>Dx1</p> 	<p>Jx1</p> 	<p>①x20+2</p>  <p>M3*14mm</p>	<p>⑦x8+1</p>  <p>M6*50mm</p>	<p>⑬x1</p> 
<p>Ex1</p> 	<p>Kx1</p> 	<p>②x24+2</p>  <p>M3*16mm</p>	<p>⑧x2</p>  <p>M8*30mm</p>	<p>⑭x2</p> 
<p>Fx1</p> 	<p>Lx1</p> 	<p>③x4</p>  <p>M3. 5*25mm</p>	<p>⑨x9+1</p>  <p>wood stick Ø8*20mm</p>	<p>⑮x2</p> 

⑨x9




Ex1
 Fx1
 Ix1
 ⑥x4




Ax1

Bx1

⑥x2




⑥x8



Cx1

④x4


⑦x2




Dx1

④x4


⑦x2



- ②x16
- ⑭x2
- ⑮x2



- Jx1
- ①x2
- ⑦x2
- ⑪x1







Kx1

①x2

⑦x2

⑪x1





Mx1


②x8

④x2


⑩x4



Lx1
③x4



Nx1
Ox1
⑤x1
⑧x2




Gx1

Hx1

①x12

⑤x2

⑫x2



①x4

⑬x1

